


2. 各部の名称と設定

2. Parts Names and Settings



Unit : mm (inch)

No.	名称	内容
①	動作表示 LED	LED名 PW 出力ユニット電源 ON により点灯
		L RUN 出力ユニットがマスター局と正常にデータ 交信しているかチェックする。 マスター局から正常なデータを受信する とき点灯、タイムオーバーにより消灯する。 (正常なデータを受信することにより点灯する)
		SD データ送信により点灯
		RD 受信データにより点灯
		L ERR. 伝送エラー (CRC エラー) により点灯、 タイムオーバーにより消灯する。(RUNも 消灯) 局番設定、伝送速度設定ミスにより点灯 (設定を修正し電源再投入により消灯) 局 番設定、伝送速度設定が途中で変化した ときERR点滅 (RUNは点灯、ユニットは 電源立上げ時の局番設定および伝送速度 設定の条件で動作する)
		0~F 入出力のON/OFF状態を表示 ON状態で点灯、OFF状態で消灯
②	伝送速度 設定	設定
		伝送速度
		0 156 kbps
		1 625 kbps
		2 2.5 Mbps
3 5 Mbps		
4 10 Mbps		
伝送速度設定スイッチは必ず0~4の範囲で設定して ください。		
③	局番設定 スイッチ	リモートI/Oユニットの局番は、必ず01~64の範 囲で設定してください。(※1) ・"X10"は、局番の10の位を設定します。 ・"X1"は、局番の1の位を設定します。
④	端子台	出力ユニット電源、伝送、入出力信号の接続用端子 台です。

* 1 局番を重複して設定することはできません。

No.	Item	Description
①	Operating status indicator LEDs	LED name PW Turns on when output module power supply is turned on.
		L RUN Check if the output module is communicating with the master station normally. Turns on when normal data is received from master station, and turns off when time is expired. (Turned on by receiving normal data.)
		SD Turns on when sending data.
		RD Turns on when receiving data.
		L ERR. Turns on when transmission error (CRC error) occurred, and turns off when time is expired. (RUN also turns off.) Turns on when station number setting or transmission speed setting is incorrect (turns off when the setting is corrected and power is restarted). ERR flashes when station number setting or transmission speed setting is changed since startup. (RUN remains on. The module keeps operating with the same station number and transmission speed settings when the power was turned on.)
		0 to F Shows on/off status of I/O. Turns on when on, turns off when off.
②	Trans- mission speed setting	Setting
		Transmission speed
		0 156 kbps
		1 625 kbps
		2 2.5 Mbps
3 5 Mbps		
4 10 Mbps		
Be sure to set the transmission speed setting switches within the range of 0 to 4.		
③	Station number setting switches	Be sure to set the station numbers of remote I/O module within the range of 01 to 64.(※1) ・"X10" sets the tens digit of the station number. ・"X1" sets the units digit of the station number.
④	Terminal block	A terminal block for connection to the output module power supply, transmission and I/O signals.

* 1 Duplicate station number cannot be set.

AJ65BTB2-16R 形 CC-Link システムリモート出力ユニットユーザーズマニュアル
AJ65BTB2-16R CC-Link System Remote Output Module User's Manual

● 安全上のご注意 ●
(ご使用前に必ずお読みください)

本製品のご使用に際しては、本マニュアルをよくお読みいた
どと共に、安全に対して十分に注意を払って、正しい取扱いをして
いただくようお願いいたします。
なお、この注意事項は本製品に関するもののみについて記載し
たものです。シーケンサシステムとしての安全上のご注意に関し
ては、CPUユニットのユーザーズマニュアルを参照してください。
この●安全上のご注意●では、安全注意事項のランクを「危険」、
「注意」として区分してあります。

危険 取扱いを誤った場合に、危険な状況が起
りえて、死亡または重傷を受ける可能性が
想定される場合。

注意 取扱いを誤った場合に、危険な状況が起
りえて、中程度の傷害や軽傷を受ける可能
性が想定される場合および物的損害だけの
発生が想定される場合。

なお、▲注意に記載した事項でも、状況によっては重大な結果
に結びつく可能性があります。
いずれも重要な内容を記載していますので必ず守ってください。
本マニュアルは必要なときに読めるように大切に保管すると共
に、必ず最終ユーザまでお届けいただくようお願いいたします。

【設計上の注意事項】

危険

- データリンクが交信異常になったとき、交信異常局は次のような状態になり
ます。
交信状態情報を使って、システムが安全側に働くようにシーケンスプログラ
ム上でインタロック回路を構成してください。
誤出力、誤動作により事故の恐れがあります。
リモートI/O局からの出力は、全点OFFします。
- リモートI/Oユニットの故障によっては、出力がON状態またはOFF状態に
なることがあります。重大な事故につながるような出力信号については、外
部で監視する回路を設けてください。

注意

- ユニットは、CPUユニットユーザーズマニュアル記載の一般仕様の環境で使
用してください。
一般仕様の範囲以外の環境で使用すると、感電、火災、誤動作、製品の損傷
あるいは劣化の原因になります。
- 制御線や通信ケーブルは、主回路や動力線などと束線したり、近接したりし
ないでください。100mm以上を目安として離してください。
ノイズにより、誤動作の原因になります。

【取付け上の注意事項】

注意

- ユニットの導電部分には直接触らないでください。
ユニットの誤動作、故障の原因になります。
- ユニットは、DIN レールまたは取付けネジにて、確実に固定し、取付けネジ
は規定トルク範囲内で確実に締め付けてください。
ネジの締め付けがゆるいと、落下、短絡、誤動作の原因になります。
ネジを締め過ぎると、ネジの破損による落下、短絡の原因になります。

【配線上の注意事項】

危険

- 配線作業などは、必ずシステムで使用している外部供給電源を全相遮断して
から行ってください。全相遮断しないと、感電あるいは製品の損傷の恐れが
あります。
- 取付け、配線作業などの後、通電、運転を行う場合は、必ず製品に付属の端
子カバーを閉めないと、感電の恐れがあります。

本マニュアルは再生紙を使用しています。

● SAFETY PRECAUTIONS ●
(Read these precautions before using.)

When using this equipment, thoroughly read this manual. Also pay careful
attention to safety and handle the module properly.
These precautions apply only to this equipment. Refer to the CPU module
user's manual for a description of the PLC system safety precautions.
These ● SAFETY PRECAUTIONS ● classify the safety precautions
into two categories: "DANGER" and "CAUTION".

DANGER Procedures which may lead to a dan-
gerous condition and cause death or
serious injury if not carried out properly.

CAUTION Procedures which may lead to a dan-
gerous condition and cause superficial to
medium injury, or physical damage only,
if not carried out properly.

Depending on circumstances, procedures indicated by ▲ CAUTION may
also result in to serious results
In any case, it is important to follow the directions for usage.
Store this manual in a safe place so that you can take it out and read it
whenever necessary. Always forward it to the end user.

(0608) MEE

【DESIGN PRECAUTIONS】

DANGER

- When a communication error occurs in the data link, the communication
error station will be in the following condition. Configure an interlocking circuit
in a sequence program using the communication status information so that
the safety of the overall system is always maintained.
Accident may occur due to output error or malfunction.
Output points from remote I/O station will be all off.
- Output could be on or off when there is trouble in the remote I/O modules.
So build an external monitoring circuit that will monitor any output signals
that could cause serious trouble.

CAUTION

- Use each module in an environment as specified in the "general
specification" in the CPU module user's manual. Usage of the module
outside the general specification range may cause electric shock, fire,
malfunction, product damage or deterioration.
- Do not have control cables and communication cables bundled with or
placed near by the main circuit and/or power cables. Wire those cables at
least 100mm(3.94 inch) away from the main circuit and/or power cables. It
may cause malfunction due to noise interference.

【INSTALLATION PRECAUTIONS】

CAUTION

- Do not directly touch the module's conductive parts.
Doing so could cause malfunction or trouble in the module.
- Tighten the module securely using DIN rail or installation screws within the
specified torque range. Loose terminal screws may cause a short circuit or
erroneous operation. If the terminal screws are too tight, it may cause falling,
short circuit or erroneous operation due to damage of the screws.

【WIRING PRECAUTIONS】

DANGER

- Completely turn off the externally supplied power used in the system when
installing or placing wiring. Not completely turning off all power could result in
electric shock or damage to the product.
- Make sure to close the terminal cover shipped with the product when starting
the power supply or operation after installation, wiring, etc.
If terminal cover is not closed an electric shock may result.

Printed in Japan on recycled paper.

注意

- FG端子はシーケンサ専用のD種接地(第三種接地)以上で必ず接地を行ってください。感電、誤動作の恐れがあります。
- 空き端子ネジは必ず締付けトルク範囲(42~50N・cm)で締付けてください。圧着端子と短絡する原因になります。
- 圧着端子は適合圧着端子を使用し、規定のトルクで締付けてください。先開形圧着端子を使用すると、端子ネジがゆるんだ場合に脱落し、故障の原因になります。
- ユニットの配線は、製品の定格電圧および端子配列を確認した上で正しく行ってください。定格と異なった電源を接続したり、誤配線すると、火災、故障の原因になります。
- 端子ネジの締付けは、規定トルク範囲内で行ってください。端子ネジの締付けがゆるいと、火災や誤動作の原因になります。端子ネジを締め過ぎると、ネジの破損による短絡、誤動作の原因になります。
- ユニットの内部、切粉や配線クズなどの異物が入らないように注意してください。火災、故障、誤動作の原因になります。
- ユニットの接続する電線やケーブルは、必ずダクトに納める、またはクランプによる固定処理を行ってください。ケーブルをダクトに納めなかったり、クランプによる固定処理をしていないと、ケーブルのふらつきや移動、不注意の張り引きなどによるユニットやケーブルの破損、ケーブルの接触不良による誤動作の原因となります。
- 制御線と通信ケーブルは束線したり、近接したりしないでください。ノイズにより、誤動作の原因になります。
- ユニットの接続された通信ケーブルや電源ケーブルを取り外すときは、ケーブル部分を手に持って引っ張らないでください。コネクタ付きのケーブルは、ユニットに接続している部分のコネクタを手で持って取り外してください。コネクタなしのケーブルは、ユニットに接続している部分のネジを緩めてから取り外してください。ユニットに接続された状態でケーブルを引っ張ると、ユニットやケーブルの破損、ケーブルの接続不良による誤動作の原因となります。

【立上げ・保守時の注意事項】

危険

- 運転中に端子に触れないでください。感電の原因になります。
- 清掃、端子ネジ、ユニット取付けネジの増し締めは、必ずシステムで使用している外部供給電源を全相遮断してから行ってください。全相遮断しないと、ユニットの故障や誤動作の原因になります。

注意

- ユニットの分解、改造はしないでください。故障、誤動作、ケガ、火災の原因になります。
- ユニットの落下させたり、強い衝撃を与えないでください。ユニットの破損の原因になります。
- ユニットの盤への取付け・取外しは必ずシステムで使用している外部供給電源を全相遮断してから行ってください。全相遮断しないと、ユニットの故障や誤動作の原因になります。
- 端子台の着脱は、製品ご使用後、50回以内としてください。(JIS B 3502準拠)
- ユニットの触れる前には、必ず接地された金属などに触れて、人体などに帯電している静電気を放電してください。静電気を放電しないと、ユニットの故障や誤動作の原因になります。

【廃棄時の注意事項】

注意

- 製品を廃棄するときは、産業廃棄物として扱ってください。

1.仕様

項目	内容	
出力点数	16点	
絶縁方式	フォトカプラ絶縁	
定格負荷電圧・電流	DC24V (抵抗負荷) / 2A / 1点 AC240V (COSφ=1) / 8A / 1コモン	
最小開閉負荷	DC5V 1mA	
最大開閉電圧	AC250V DC110V	
応答時間	OFF → ON	10msec 以下
	ON → OFF	12msec 以下
寿命	機械的	2000 回以上
	電氣的	定格開閉電圧・電流負荷 10 万回以上 AC200V 1.5A, AC240V 1A (COSφ=0.7) 10 万回以上 AC200V 1A, AC240V 0.5A (COSφ=0.35) 10 万回以上 DC24V 1A, DC100V 0.1A (L/R=7msec) 10 万回以上

CAUTION

- Always ground the FG terminal. There is a risk of electric shock or malfunction.
- Be sure to tighten any unused terminal screws within a tightening torque range (42 to 50N・cm). Failure to do so may cause a short circuit due to contact with a solderless terminal.
- Use applicable solderless terminals and tighten them with the specified torque. If any solderless spade terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
- Perform correct wiring for the module according to the product's rated voltage and terminal arrangement. Connecting to a power supply different from rating or miss-wiring may cause fire and/or product failure.
- Fix terminal screws securely within the regulated torque. Loose terminal screws may cause fire and/or malfunction. If the terminal screws are too tight, it may cause short circuit or erroneous operation due to damage of the screws.
- Make sure foreign objects do not get inside the module, such as dirt and wire chips. It may cause fire, product failure or malfunction.
- Be sure to fix the wires or cables by ducts or clamps when connecting them to the module. Failure to do so may cause damage of the module or the cables due to accidental pull or unintentional shifting of the cables, or malfunctions due to poor contact of the cable.
- Do not install the control lines together with the communication cables, or bring them close to each other. Failure to do so may cause malfunctions due to noise.
- When disconnecting a communication or power supply cable from the module, do not pull on the cable itself. Disconnect cables not fitted with a connector by holding and pulling the cable connector. Disconnect cables not fitted with a connector by removing the screws from the part connected to the module can cause damage to the module or cable, or malfunction due to cable connection faults.

【STARTING AND MAINTENANCE PRECAUTIONS】

DANGER

- Do not touch terminals when the power is on. Doing so could cause an electric shock.
- Switch off all phases of the externally supplied power used in the system when cleaning the module or retightening the terminal or module mounting screws. Not doing so could result in electric shock.

CAUTION

- Never try to disassemble or modify module. It may cause product failure, malfunction, fire or cause injury.
- Do not drop or apply any strong impact to the module. Doing so may damage the module.
- Completely turn off the externally supplied power used in the system before mounting or removing the module to/from the panel. Not doing so could result in damage to the product.
- Mounting/removing the terminal block is limited to 50 times after using a product. (IEC61131-2-compliant)
- Always make sure to touch the grounded metal to discharge the electricity charged in the electricity charged in the body, etc., before touching the module. Failure to do so may cause a failure or malfunctions of the module.

【DISPOSAL PRECAUTIONS】

CAUTION

- When disposing of this product, treat it as industrial waste.

1. Specification

Item	Description	
Number of output points	16 points	
Isolation method	Photocoupler	
Rated switching voltage /current	24 VDC(resistive load) / 2 A/point 240 VAC(COSφ=1) / 8 A/common	
Min. switching load	5 VDC 1 mA	
Max. switching voltage	250 VAC 110 VDC	
Response time	OFF → ON	10 msec or lower
	ON → OFF	12 msec or lower
Service life	Mechanical	More than 20 million times
	Electrical	Rated switching voltage/current loads more than 100,000 time 200 VAC 1.5 A, 240 VAC 1 A (COSφ=0.7) more than 100,000 times 200 VAC 1 A, 240 VAC 0.5 A (COSφ=0.35) more than 100,000 times 24 VDC 1 A, 100 VDC 0.1 A (L/R=7 msec) more than 100,000 times

項目	内容	
最大開閉頻度	3600 回/時	
出力部外部供給電源 (CTL+, CTLG)	電圧	DC24V ± 10%リップル率 4Vp-p 以下
	電流	90mA 以下 (TYP.DC24V 全点 ON)
サージキラー	なし	
コモン方式	8点 1コモン (2線式端子台)	
占有局数	1局	
I/Oユニット電源	電圧	DC15.6~28.8V (リップル率 5%以内)
	電流	85mA 以下 (TYP.DC24V 時)
ノイズ耐量	ACタイプのノイズ電圧 1500Vp-p, DCタイプのノイズ電圧 500Vp-p ノイズ幅 1μs, ノイズ周波数 25~60Hzのノイズシミュレータによる	
耐電圧	AC外部端子一括 アース間 AC1500V 1分間 DC外部端子一括 アース間 AC500V 1分間	
絶縁抵抗	AC/DC-外部端子一括 アース間 DC500V 絶縁抵抗計にて 10MΩ 以上	
質量	470g	
外部接続方式	37点端子台 (M3.5ネジ締付けトルク 59~88N・cm) 伝送回路、ユニット電源端子含む	
適合電線サイズ	0.75~2mm ²	
ユニット取付けネジ	M4 × 0.7mm × 16mm 以上ネジ (締付けトルク範囲 78~118N・cm) DIN レールでの取付けも可能	
適用 DIN レール	TH35-7.5Fe, TH35-7.5Al, TH35-15Fe (JIS C 2812 に準拠)	
適合圧着端子	RAV 1.25-3.5 (JIS C 2805 に準拠) RAV 2-3.5	

Item	Description	
Max. switching frequency	3600 times/hour	
External Power supply for output (CTL+, CTLG)	Voltage	24 VDC ± 10 % ripple ratio: 4 Vp-p or lower
	Current	90 mA or lower (TYP.24 ADC all point ON)
Surge suppression	None	
Common method	8 points/common (2-wire terminal block)	
Number of stations occupied	1 station	
I/O module power supply	Voltage	15.6 to 28.8 VDC(ripple ratio: within 5 %)
	Current	85 mA or lower (at TYP.24 VDC)
Noise durability	AC type noise voltage 1500Vp-p, DC type noise voltage 500Vp-p, Noise width 1μs, Noise frequency 25 to 60Hz(noise simulator condition)	
Withstanding voltage	1500 VAC for 1 minute between all AC external terminals together and ground 500 VAC for 1 minute between all DC external terminals together and ground	
Insulation resistance	10 MΩ or higher, measured with a 500 VDC insulation resistance tester	
Weight	470 g (1.0 lb)	
External wiring system	37-point terminal block(M3.5 screws tightening torque: 59 to 88 N・cm) including transmission circuit, and module power supply terminal	
Applicable wire size	0.75 to 2 mm ²	
Module installation screw	M4(0.16) × 0.7 mm(0.03) × 16 mm (0.63) screws (tightening torque range 78 to 118 N・cm) DIN rails can be used for installation	
Applicable DIN rail	TH35-7.5Fe, TH35-7.5Al, TH35-15Fe (conforming to IEC 60715)	
Applicable solderless terminal	RAV 1.25-3.5(JIS C 2805 conforming) RAV 2-3.5	

